

40 Huntingwood Drive Huntingwood NSW 2148

Phone: (02) 8825 1999 Website: www.aeroflowperformance.com

INSTALLATION MANUAL AEROFLOW PERFORMANCE ALUMINIUM BARE CYLINDER HEADS

WARNING!

BEFORE PROCEEDING WITH INSTALLATION PLEASE READ INSTRUCTIONS CAREFULLY. THIS PRODUCT REQUIRES DETAILED KNOWLEDGE OF AUTOMOTIVE SYSTEMS. WE RECOMMEND THAT THIS INSTALLATION BE CARRIED OUT BY A QUALIFIED AUTOMOTIVE TECHNICIAN.

PLEASE CHECK THE HEAD THOROUGHLY IN EVERY POSSIBLE WAY. IF YOU SUSPECT A DEFECT OR SHIPPING DAMAGE, CONTACT AEROFLOW PERFORMANCE OR THE DEALER IT WAS PURCHASED FROM BEFORE ANY WORK HAS BEGUN. AEROFLOW PERFORMANCE WILL NOT BE RESPONSIBLE FOR DEFECTS AFTER ANY WORK HAS BEEN STARTED.

INTRODUCTION

Congratulations on your purchase of Aeroflow Performance Cylinder Head. Aeroflow Performance products cannot and will not be responsible for any damage, or other conditions resulting from misapplication of the parts described herein. However, it is our intention to provide the best possible products for our customer, products that perform properly and satisfy your expectations. Should you have any questions? Please call technical support at +61 2 8825 1979 and have the product part number on hand when calling.

The Aeroflow Ford FE Aluminium Cylinder Heads are taking affordable performance street and strip cylinder heads to the next level. These heads utilise ultra-smooth A356-T6 aluminium castings, new as-cast runner and chamber designs produce CNC flow numbers. These Ford FE heads have 170cc intake runners, combined with diamond-honed bronze guides and hand bowl blending to outperform some of the best brands in the business.

Cylinder One Flow Testing on Flow Bench
NOTE: ALL FLOWBENCHES ARE NOT CREATED EQUAL!
Data from one bench to the next can be vastly different.
The data on this table is for reference only.

Port	Lift	L/D	Cylinder One Average CFM	Port	Lift	L/D	Cylinder One Average CFM	
Intake	0.100	0.050	65.500	Exhaust	0.100	0.063	53.500	
Intake	0.200	0.099	123.700	Exhaust	0.200	0.125	97.100	
Intake	0.300	0.149	183.400	Exhaust	0.300	0.188	136.100	
Intake	0.400	0.198	239.200	Exhaust	0.400	0.250	173.000	
Intake	0.500	0.248	267.600	Exhaust	0.500	0.313	193.000	
Intake	0.600	0.297	287.100	Exhaust	0.600	0.375	202.800	
Intake	0.650	0.322	298.300	Exhaust	0.650	0.406	208.200	

For more information or technical enquires

Contact: Aeroflow Performance on

Phone: (02) 8825 1979 Website: www.aeroflowperformance.com

SPECIFICATIONS					
Material	A356 Aluminum				
Combustion Chamber CC	72cc				
Intake Port Volume CC	170cc				
Intake Port Dimension	2.065" x 1.36"				
Exhaust Port Volume CC	125cc				
Exhaust Port Dimension	1.85"H x 1.27"W				
Spark Plug Location	Angled				
Intake Valve Diameter	2.09"				
Exhaust Valve Diameter	1.66"				
Valve Stem Diameter	3/8" (.375")				
Valve Spring Pocket I.D.	1.725"				
Valve Guide Material	Manganese Bronze				
Valve Guide O.D.	0.562"				
Rocker Stud Thread Size	Shaft type				
Valve Angle	13 Degree				
Deck Thickness	0.625"				

Hydraulic / Solid Flat Tappet (up to .580")
Hydraulic Roller Cam (up to .580" lift)
(Check Cam Manufacturer Recommendation)

Installed Components	Sizes					
Intake Valves	2 .09" x 5.45" x 3/8"					
Exhaust Valves	1.66" x 5.45" x 3/8"					
Valve Springs	Per cam spec					
Valve Retainers	Per spring spec					
Valve Locks	Per spring spec					
Valve Seals	3/8" x .562"					
Spark Plugs	Champion RC9YC					



For more information or technical enquires

Contact: Aeroflow Performance on

Phone: (02) 8825 1979 Website: www.aeroflowperformance.com

Installation Guideline

For a complete installation of these Aeroflow Performance cylinder heads you will require some extra components other than the original parts that must be purchased separately. Being a bare cylinder head, they will require all internal components such as valves, valve springs, rocker assembly to be installed and purchased separately. Bronze guides are preinstalled into the cylinder head. We recommend a cylinder head / machinist specialist to install these components.

Installation is the same as for original equipment cylinder heads. Consult the factory service manual for specific procedures, if necessary.

Once the heads have been installed and torqued to specs, install your pushrods, rocker arms, and rocker arm adjusting nuts.

The following list is a guideline of suggested parts that may or may not need to be purchased;

- ➤ Head gaskets
- ➤ Intake manifold gaskets
- > Exhaust gaskets
- ➤ Valve Cover gaskets
- ➤ Head bolt or Head Stud kit (**OEM head bolts are not compatible**)
- > 14mm x 3/4" reach x 5/8" hex, gasket spark plugs (heat range to be determined by specific application)
- > Adjustable rocker arm assembly
- > Aftermarket rocker shaft stud kit
- > Pushrods compatible with adjustable rocker arm assembly (length to be determined by specific application once all rocker assembly is installed)

Although these cylinder heads will accept OEM components (rocker arms, valve covers, intake manifold, etc.), we highly recommend that premium quality hardware be replaced with your new heads.

- o Check with the camshaft manufacturer for recommended valve spring with correct pressures and maximum valve lift. If valve springs are changed to achieve more spring pressures it will be necessary to also change rocker studs, rocker arms and pushrods. All valve springs should be checked for compatibility to your camshaft. Severe wear of valve train components and severe engine damage could result from failure to do this. Check spring requirements before heads are installed on the engine.
- High quality head studs or head bolts with hardened washers must be used to prevent galling of the aluminium bolt bosses. Bolt threads, underside of bolt heads, and washers should be lubricated with an oil/moly mix prior to installation and torquing. OEM head bolts are not compatible.
- o These cylinder heads accept 14mm x 3/4" reach gasket seat spark plugs. Heat range may vary by application. Use anti-seize on the plug threads to prevent galling in the cylinder head, and torque to 13Nm.

It is highly recommended that valve-to-piston clearances are checked and corrected to minimum specs, if necessary. Minimum intake valve clearance should be .100". Minimum exhaust valve clearance should be .110".

It is highly recommended that piston-to-head clearances are checked and corrected to minimum specs. Especially when using a dome piston. Recommended minimum piston-to-head clearance is .050".

Rocker geometry should be checked, making sure that the contact point of the roller (or pad on a stock rocker arm) remains properly on the valve tip and does not roll off the edge. Visual inspection of the rockers, valve springs, retainers, and pushrods should be made to ensure that none of these components come into improper contact with each other. If problems with valve train geometry occur, changes such as pushrod length may have to be made.

When using factory rocker shaft bolts check to ensure the bolts do not bottom out in the cylinder heads and that the bolt is long enough to engage with the entire length of the heli-coil thread insert in the cylinder heads. When installing the rocker shaft assembly, tighten the bolts evenly as the rocker shaft assembly is being pulled down into position against the pressure of the valve springs. Use engine oil on the bolt threads and bolt head. Tighten bolts to 40-45 Ft-lbs.

We recommend all pushrod guide plates and rocker studs are checked for proper valve train alignment and pushrod clearance before operating the engine. Ensure the stud holes have enough clearance to adjust the guide plates for optimum alignment of your valve train components. Once the cylinder heads have been installed ensure to the check the pushrod-to-cylinder head clearance. The clearance between the pushrods and the cylinder heads must be 005" min. If adequate clearance exists between pushrod and head, slowly turn the engine over through at least two full revolutions while inspecting pushrods and rocker arm components. Make sure that pushrod and/or rocker arm components do not rub on the head either at full lift or when the valve is seated closed. If any pushrod rubs on the cylinder head, remove rocker arms, loosen the rocker studs and move the guide plates as needed to provide clearance. After checking all pushrods for proper clearance, ensure that the tip of the rocker arm is making adequate contact with the top of the valve stem. Carefully re-torque to 60Nm any rocker studs that were loosened. Check alignment again to be sure that the guide plates did not move while torquing the studs.

For more information or technical enquires

Contact: Aeroflow Performance on

Phone: (02) 8825 1979 Website: www.aeroflowperformance.com